

Tetratec®

HT 25 / HT 50 / HT 75 / HT 100 / HT 150 / HT 200 / HT 300



Tetra^{tec}[®]



HT 25 / HT 50 / HT 75 / HT 100 / HT 150 / HT 200 / HT 300

Instructions for use

Congratulations on the purchase of your Tetra^{tec} heater thermostat. This TÜV tested heater-thermostat is manufactured from the highest quality materials and uses the latest aquarium heater technology. As a result you can be sure of its accuracy, reliability and safety. Add to this its simplicity of use and you have a heater thermostat that you can simply „set and forget“, leaving it to maintain the desired water temperature and leaving you to enjoy your fishkeeping.

Please observe the following instructions when installing and using your Tetra^{tec} heater thermostat:

1. Fasten the enclosed adhesive suckers to the points provided on the HT heater thermostat (see fig.)
2. Set the desired temperature (2) using the adjusting knob (1).
3. Fasten the Tetra^{tec} thermostat heater in the aquarium using the adhesive suckers (see fig. 3). To ensure the best temperature regulation, choose a place where the water is continuously circulating (i.e. near a filter or pump). Please ensure that the heater is always immersed up to the minimum water level mark.
4. After installing the heater, insert the plug into the mains socket. The thermostat takes several minutes to register the water temperature. The device switches on or off as soon as the temperature deviates from the desired temperature setting by ± 0.25 degrees Celsius. In this way the Tetra HT thermostat heater automatically keeps the water at the desired temperature. The control lamp illuminates whenever the heater is on. Minor deviations between the adjusted temperature of the heater and the indication of an aquarium thermometer are sometimes possible.

Safety regulations

Important

The HT heater thermostat should only be connected to the mains once it has been immersed up to the minimum water level mark. Before putting your hand into the water for any reason, disconnect the heater thermostat and all other electrical devices from the mains! The heater thermostat should be left for 15 minutes after disconnecting from the mains before removal, or before reducing the water level to below the minimum water level mark. Failure to do so could result in the unit cracking. The HT heater thermostat should only be used for indoor aquaria.

The connection lead cannot be replaced. If the lead is damaged, the device should be scrapped. Ensure that the water level does not drop below the minimum water level mark.

2 year guarantee (Please see enclosed guarantee card).

As a result of modern manufacturing technology, high-quality components and stringent quality control your Tetra HT heater thermostat is guaranteed for 2 years from the date of purchase. Guarantee claims will only be considered if accompanied by a proof of purchase. The guarantee does not cover normal wear and tear, nor any deterioration suffered through overloading, improper use, negligence or accident.

Should you have any queries, please contact your specialist dealer directly, or Tetra PO Box 271, Southampton, SO18 3ZX, England, www.tetra.net

Tetra GmbH
D-49304 Melle, Germany
www.tetra.net

